

Akai MPK 249

Setup

Connect the Akai MPK 249 to your computer.

To control Cubase/Nuendo with the Akai MPK 249 make sure to use **hardware preset 10 'Cubase'**.

If the hardware preset 10 has been changed, you must **restore the factory default Presets**.

If you use WinRT MIDI, connect the controller to the computer before you start Cubase/Nuendo. Otherwise, the controller will not be detected.

