

Akai MPK mini mk2

Setup

Connect the Akai MPK mini mk2 to your computer.

Use any combination of the **BANK A/B** and **CC** buttons to control Cubase/Nuendo using the pads. 4 pad banks are available:

Hardware button combination	Cubase/Nuendo Control Layer Name
Bank A/B (green) + CC Off	Bank A - 1/4
Bank A/B (red) + CC Off	Bank B - 2/4
Bank A/B (green) + CC On	Bank A + CC - 3/4
Bank A/B (red) + CC On	Bank B + CC - 4/4

