

## Avatar EMP-16


Connect EMP-16 to the computer (via USB or wireless), EMP-16 will automatically switch to the Cubase parameter group.

将 EMP-16 连接到电脑（通过 USB 或无线），EMP-16 将自动切换到 Cubase 参数组。



MIDI mapping of the Cubase script.

Cubase 脚本的 MIDI 映射关系。



EMP-16 MIDI Channel :10

Knob

#### Control Bank A -1

Knob1	-	CC#70
Knob2	-	CC#71
Knob3	-	CC#72
Knob4	-	CC#73

#### Control Bank B-2

Knob5	-	CC#74
Knob6	-	CC#75
Knob7	-	CC#76
Knob8	-	CC#77

#### Control Bank C-3

Knob8	-	CC#78
Knob9	-	CC#79
Knob10	-	CC#80
Knob11	-	CC#81

#### **Tape Transport**

Start	-	CC#59
Record	-	CC#60
Activate Cycle	-	CC#61
Forward	-	CC#62
Rewind	-	CC#63

#### **Pad**

##### Control Bank A - 1

PAD1-PAD16	-	Note36-Note51
------------	---	---------------

##### Control Bank B - 2

PAD17-PAD32	-	Note52-Note67
-------------	---	---------------

##### Control Bank C - 3

PAD33-PAD48	-	Note68-Note83
-------------	---	---------------

##### Control Bank C - 4

PAD49-PAD64	-	Note20-Note35
-------------	---	---------------

#### **Fader**

Fader1	-	CC#12
Fader2	-	CC#13
Fader3	-	CC#14
Fader4	-	CC#15

